


TAMÍZ L

Assembly instructions



nomon
JEWELRY FOR HOME

1




Take the lamp out of the box with care.
Saque la lámpara de la caja con cuidado.




x1 

2



3



WARNING!

- Never cover the luminaire.
- Disconnect power supply before installation and change of the bulb.
- If the wire or flexible cord is damaged, it must only be change by the manufacturer, their Service Dept. or qualified personnel in order to avoid risk.



Installation of this material can be dangerous and must be done by qualified personnel.



ATENCIÓN!

- No cubra la luminaria.
- Desconectar la conexión a red antes de ser manipulada y realizar el cambio de bombilla.
- Si el cable flexible o cordón de esta luminaria es dañado, deberá sustituirse exclusivamente por el fabricante o su servicio técnico o una persona de cualificación equivalente con objeto de evitar cualquier riesgo.




La instalación de este material podría ser peligroso y por ello se ha de hacer por personal cualificado.


4

In order to replace the light bulb, if necessary, put the lamp upside down and unscrew the wooden base using the provided Allen key.

Para reemplazar la bombilla, si es necesario, coloque la lámpara boca abajo y desenrosque la base de madera utilizando la llave Allen suministrada.



5



Reach inside the lampshade to unscrew and replace the bulb.

Acceda con la mano en el interior de la pantalla para desenroscar y cambiar la bombilla.

WE CREATE JEWELRY FOR YOUR HOME



Technical data

- Light fitting for indoor use only
- Bulb to be used:
E27 • LED • 2452lm • 2700K
- Recommended brands:
Philips • Osram

Datos técnicos

- Luminaria para uso interior
- Bombilla a utilizar:
E27 • LED • 2452lm • 2700K
- Marcas recomendadas:
Philips • Osram



IP 20
~230V-50/60Hz

